



# Printing Pinnacle Test Chart for Epson 3800 & iMac


## Setting Colour Management Off / Selecting Media Type






Having selected Print Settings from the above the window on the left is displayed


Clicking the up / down arrows on the Layout Button the options on the right are displayed






Choosing Color Matching the window on the left is displayed

Now select Epson Color Controls. Click up / down arrows on Color Matching and select Print Settings.





Click the up / down arrows on Color Settings and choose Off (No Color Adjustment)

Print

Printer: EPSON Stylus Pro 3800

Presets: Default Settings

Paper Size: A4 210 by 297 mm

Print Settings

Basic Advanced Color Settings

Page Setup: Sheet Feeder

Media Type: Premium Photo Paper Glossy

Ink: Photo Black

Color: Color  16 bit/Channel

Color Settings:  Color Controls

Print Quality:  Off (No Color Adjustment)

High Speed

Flip Horizontal

Finest Detail



PDF

Hide Details




Low Ink


Cancel

Save


Now select the appropriate media type.



Note however if you select Fine Art Paper the options are greyed out. This is because Fine Art Papers have to be fed from the rear.







Select Paper Size and a range of paper sizes is displayed. If you click on A4 there are various options, select A4 (Manual - Rear).



If you now select Media Type - Fine Art Paper the various options are now available to you. Note that this printer will only print Fine Art papers that are manually fed into the rear slot

